



www.cruzee.com

Assembly Manual



Cruzee North America LLC
 907 Aviator Drive
 Fort Worth, Texas 76179
 USA
 +1-513-427-8933

Designed in U.S.A.
 ©2015 Alchemy Metals
 Made in Taiwan





Unpack your Cruzeel!

Seat/Seatpost (Short) (x1)
Seatpost (Long) (x1)

Handlebar set (x1)

Seat Quick Clamp (x1)







Warnings

Small parts.
Protective equipment
should be worn.
Not to be used in traffic.
This bike has no brakes.
75 lbs (34 kg.) max.

Handlebar & Front Wheel Assembly



1. Open cam lever.
(fig. A)

2. Remove clamp and upper bushing.
(fig. B)

3. Insert front fork assembly.
(fig. C.)


4. Replace clamp and upper bushing onto top of fork tube.
(fig. C.)




5. Insert handlebar into fork tube.
(fig. D.)

6. Align handlebar and wheel.
(fig. D.)

7. Close cam lever.
(fig. E.)

ATTENTION! Headset Bushing Correct Allignment






For online instructions
and assembly video,
scan this code.



Or go to online to:
www.cruzee.com/assembly



8. Open quick clamp.
(fig. F)

9. Insert seatpost assembly.
(fig. F)

10. Adjust seat height, align
with frame and close quick
clamp lever.
(fig. G)

Proper Seat Height:

Proper seat height should allow the child to sit on the bike with both feet flat on the ground with a slight bend in his or her knees.



For Taller Riders:

Your Cruzee comes with a short seatpost assembled to the seat plus an additional long seatpost included in the box. This provides maximum adjustability for your child. When the long seatpost is needed, simply unscrew the screw on the back of the seat, swap seatposts, and insert the screw to secure the seat.

WARNING

- Your Cruzee is equipped with two quick clamp mechanisms to facilitate installation and adjustment of the seat and handlebar height. Failure to properly install this quick clamp on your bicycle may cause the seat or handlebar to become detached from the bicycle while you are riding and result in serious bodily injury.
- A quick clamp is a mechanism that uses a lever to tighten or loosen the clamp.
- When swinging the quick clamp lever from open to closed, the clamp should grip firmly. This will fix the handlebar or seatpost in place.




fig. 1 Closed






fig. 2 Open

CAUTION

- Be sure to operate the quick clamp lever by hand only. Never use any other tool such as a hammer to tighten the quick clamp lever, as this could cause damage to the lever and/or clamp.



DO NOT TWIST!

Make sure that the quick clamp levers are pushed fully to the closed position (fig. 1)

Note: If the quick clamp lever can be *easily* pushed to the closed position, this means the clamping strength is insufficient. Return the quick clamp lever to the open position and rotate the adjuster nut 1/8 of a turn *clockwise*. Again, swing the lever (do not twist or turn, fig. 4) to the closed position. The clamp should be tight enough to keep height position and not allow the seat or handlebar to be moved with force of hands.

If closing the clamp requires a too much force you can reduce the force by rotating the adjuster nut. Start with 1/8 of a *counter-clockwise* turn and try to close again.

PLEASE READ AND FULLY UNDERSTAND THIS MANUAL BEFORE OPERATION.



WARNINGS:

- **CHOKING HAZARD** - Un-assembled bike and packaging contain small parts. Keep away from small children.
- Like other bicycles, using the Cruzee balance bike can be dangerous and may result in injury or death even when used with proper safety precautions. Use common sense and at your own risk.
- Properly dispose of all plastic wrapping and packaging materials.
- This partially assembled bike requires full assembly by an adult according to this manual.
- Adult supervision is required at all times.
- Do not adjust above the minimum insertion line marked on the handlebars and seatpost.
- Height range for usage is from 23.5" - 47" (60 cm ~ 120 cm). Maximum load should not exceed 75 lbs (34 kg). Approved for children 3 and above.
- Never ride near steps, public roads, vehicle traffic, water, swimming pools, sloped driveways, hills, wet / icy conditions, at night, or on rough and uneven surfaces. For use on smooth surfaces away from safety hazards only.
- The Cruzee has no brakes. Riders must stop with their feet. The rider should not ride faster than he or she can stop safely and controllably.
- Only one rider at a time. Never allow more than one rider on a Cruzee balance bike.
- The seat should be adjusted properly so that the rider can touch the ground at all times.
- Always wear a helmet when riding. Failure to wear a properly adjusted and fitted helmet when riding can result in serious injury or death.
- Cruzee riders should always wear proper protective equipment.
- Wash your Cruzee with mild soap and water.
- Please retain this document for future reference.

Your Cruzee comes with a 2-YEAR WARRANTY against manufacturing defects. However, at Cruzee we believe in customers for life. Register your Cruzee online, and we will extend a LIFETIME WARRANTY to the original owner. Go to www.cruzee.com/warranty to secure your LIFETIME WARRANTY.



**REGISTER YOUR
CRUZEE NOW!**



Seat Height: 11" - 19" (28 - 48 cm)